

Battery Monitor V2.1.12

Operating instructions of the upper monitor

1、Unpress the upper monitor file

 BatteryMonitor V2.1.12_20并_中性

2、Open the upper monitor software

- 1) Double-click to open the decompression file
- 2) Double-click to open the drawing upper monitor executable,Figure 2-1

名称	修改日期	类型	大小
Agreement	2023/3/20 13:46	文件夹	
de	2023/3/20 13:46	文件夹	
es	2023/3/20 13:46	文件夹	
ja	2023/3/20 13:46	文件夹	
Languages	2023/3/20 13:46	文件夹	
logs	2023/3/20 13:46	文件夹	
RealTimeRecord	2023/3/20 13:46	文件夹	
ru	2023/3/20 13:46	文件夹	
 BatteryMonitor	2023/3/20 13:45	应用程序	2,091 KB
 BatteryMonitor.exe	2023/3/20 13:45	XML Configurati...	3 KB
 BatteryMonitor.pdb	2023/3/20 13:45	PDB 文件	522 KB
 BMS Upper Computer Guidance V2.1.9	2023/3/20 13:45	WPS PDF 文档	3,922 KB
 DevExpress.Data.v15.2.dll	2023/3/20 13:45	应用程序扩展	5,082 KB
 DevExpress.Data.v15.2	2023/3/20 13:45	XML 文件	1,098 KB
 DevExpress.Images.v15.2.dll	2023/3/20 13:45	应用程序扩展	3,221 KB

Figure 2-1

3、Load the upper monitor protocol

- 1) Open the upper monitor, click "Import Protocol", and select "Agreement" in the upper monitor file to open,Figure 3-1




Figure 3-1

- 2) Select the protocol file corresponding to the string, the prefix EN corresponds to the English protocol, the prefix without EN corresponds to the English protocol (example: 16 string English protocol-----16S_V20_ADDR_EN), click open,Figure3-2




Figure 3-2

3) Click to determine,Figure3-3




Figure 3-3

4、Communication port configuration

- 1) Select serial port (upper monitor automatic identification USB to 485 serial port, string slogan automatic recognition)
- 2) Baud rate: 19200
- 3) Click on the connection,Figure 4-1




Figure 4-1

4) After a successful connection, the upper monitor will displays the battery data, Figure 4-2




Figure 4-2

5、Login

Username:admin

Password:admin

Figure 5-1




Figure 5-1

6. Load parameters and upload parameters

Load parameters: Download the parameters from the upper monitor to the BMS

Upload parameters: From the BMS upload parameters to the upper monitor

6.1、Load parameters

- 1) For the first load parameters, you need to "upload parameters" and then "close",Figure 6-1




Figure 6-1

- 2) Click "Load Parameters" to select the parameter document to load,Figure 6-2




Figure 6-2

- 3) Click "Set All", the prompt box pop up, and then click "Close" to complete the configuration,Figure 6-3




Figure 6-3

6.2、Modify parameters

- 1) Click "Upload parameters" to upload the parameters from BMS
- 2) Change the BMS parameters and functional switches as required
- 3) Click "Set all" to complete the modification,Figure 6-4

Note: Follow the order of the red font in the figure




Figure6-4

7、Configuration of the communication protocol

- 1) Click the "CAN" drop-down box and select the corresponding CAN protocol according to the inverter type, Figure 7-1

Note: The 485 protocol is self-adapted and does not require manual selection

For CAN, the protocol has 6 options:

protocol type	Supported inverter brand
PN-GDLT	派能 PYLON、固德威 GOODWE、德业 Deye、鹏城 LUXPOWER、TBB
GRWT	吉瑞瓦特 Growatt---SPF、SPH
VCTR	Victron
SMA-SF	SMA、首航 SOFAR
GINL	锦浪 Solis
STUD	Studer




Figure 7-1

2) Click "Close" to complete the configuration,Figure 7-2






Figure 7-2

3) Click "Refresh", the manufacturer information will display the corresponding inverter manufacturer information,Figure 7-3






Figure 7-3

8、Show page introduction

After the successful connection, the following red box refers to the display interface, Figure 8-1 and Table 8.1




Figure 8-1

definition	instruction	prompt	expression
Max voltage	Maximum voltage value and battery cell number		Max voltage: C9
Min voltage	Minimum voltage value and battery cell number		Min voltage: C16

Differential pressure	The voltage difference between the maximum voltage and the minimum voltage		
Battery voltage	Total battery voltage		
Current	Charging current or discharge current (negative value)		
Remaining capacity	Present battery capacity	Upload parameters Num59 can set the current capacity	
Total capacity	Actual capacity after full charge		
SOC	% Residual capacity	Remaining capacity / total capacity of * 100%	
Rated capacity	Rated capacity	Upload parameters Num58 sets the capacity	
Battery cycle	Cycle index	When the cumulative discharge capacity reaches 80% of the full capacity, the cycle number will be increased once	
SOH	Health condition		
Bus voltage	Port voltage. External voltage detection	When there is no external connection, the bus voltage is equal to the total battery voltage	
Discharge switch	Discharge switch indicator lamp	Green: Switch is connected Grey: the switch is off	
Charge switch	Charging switch indicator lamp	Green: Switch is connected Grey: the switch is off	
Current limit switch	Current-limiting switch indicator light	Green: Switch is connected Grey: the switch is off	

Temperature control switch	Temperature control switch indicator lamp	Green: Switch is connected Grey: the switch is off	<input type="radio"/> Temperature control switch
Warning and protection	BMS warning and protection display areas		<input checked="" type="checkbox"/> Warn and Protect <input type="checkbox"/> None warn
Battery temperature	The 4 battery temperature values		<input type="checkbox"/> Battery temp1 20.8 °C <input type="checkbox"/> Battery temp2 21.5 °C <input type="checkbox"/> Battery temp3 21.7 °C <input type="checkbox"/> Battery temp4 22.4 °C
Ambient temperature	Ambient temperature value		<input type="checkbox"/> Ambient temp 25.1 °C
Power temperature	Power temperature value		<input type="checkbox"/> Power temp 21.8 °C

Table 8.1

8.2、 Parallel mode

1) Parallel selection

When multiple batteries (up to 20 groups) are connected in parallel, ensure that the BMS dial address (optional auto dial) is consistent with the address set by the upper monitor (pack x) (click the upper computer pack x icon to light up or turn gray), Figure 8-2




Figure 8-2

- 2) When confirming the number of connected machines, click Connect the upper monitor and select “Cycle Refresh”. The upper monitor can see the number of parallel machines and package the refresh data,Figure 8-3




Figure 8-3

- 3) On the upper monitor interface, you can click “Multiple” to view each group of package data,Figure 8-4




Figure 8-4

9. Firmware Update

- The upper monitor is disconnected, click "firmware update", select the corresponding port number, and the port rate to select 19200, and click "Open",Figure 9-1




Figure 9-1

- Click "Folder" to select the program to be upgraded in the prompt box (ehex),Figure 9-2





Figure 9-2

- 3) Click "Download" to show the download progress. If the error is reported, please try several times, Figure 9-3



- 4) After the program is downloaded, the prompt download is successful, and click "OK" to complete the upgrade, Figure 9-4




Figure 9-4

Note: This upgrade software can also be upgraded according to the corresponding address. If the BMS address matches the address of the package number, you can upgrade, Figure 9-5




Figure 9-5